


# CR-Reader Guide


# Entering the Property with a Card/Fob

Tap the credential card/fob against the Reader to unlock it.



# Entering the Property with Bluetooth

1. Download the CellGate application. 
2. Open the menu, click **Virtual Keys**, then **Personal Keys**.
3. When prompted, allow CellGate to use Bluetooth.
4. Click **Enable Bluetooth Background Access**.



5. Your phone is now ready for Bluetooth access.
6. To enter the property, have the phone on your person and wave in front of the device.